

AuthentiKit

**Universal Hub Version One
Wiring & BU0836A Configuration**

Universal Hub Version One

MISC1 and MISC2 are reserved for aircraft with different configurations. e.g. Quadrant without bomb drop

Sorry, but we will need to wait for V2 to support aileron trim, magnetos, start/coil buttons. Rome wasn't built in a day.

MISC 2

FLAPS LEVER

MISC 1

RUDDER TRIM

ENGINE TWO

ELEVATOR TRIM

COWL / RADIATOR

THROTTLE QUAD

LANDING GEAR


FLIGHT STICK

Controls in blue come with the Universal Hub Upgrade Kit

Controls in yellow were part of the Universal Hub Starter Kit


BU0836A AuthentiKit Configuration

Version 1



BU0836A AuthentiKit Configuration

FLIGHT STICK WIRING




BU0836A AuthentiKit Configuration

THROTTLE QUADRANT




We did this as part of the universal hub starter kit.
Included here for completeness



BU0836A AuthentiKit Configuration


TRIM WHEELS

We did this as part of the universal hub starter kit. Included here for completeness




BU0836A AuthentiKit Configuration

Flaps Lever




BU0836A AuthentiKit Configuration

Landing Gear - Toggle Only :- (



BU0836A AuthentiKit Configuration

Landing Gear - Radiator Lever / Cowl Flaps



BU0836A AuthentiKit Configuration

Engine Two

